


MSS PARTS LIST



Part No.	Description	Part No.	Description
1	Motor	14**	Bearing
4	Shaft	15**	Circlip
5	Outer Rotor	18	Hex Nut & Stud
6	Inner Rotor	19	Impeller
7	Shroud	22	Gearbox
10	Rotor	26	Stop Screw
11**	Bearing	36	Circlip
12**	Circlip		
13	Adapter		

** Recommended Spare Parts